

Electric Strikes

2 Series Offset Electric Strike/Mortise Lock Cross-Reference



In or Out...we make it Easy!®

Lockset Manufacturer	Strike Model	Handing	DOOR Dimension from C/L of Offset Lock Latch to C/L of Lock Face
American Device	2124/2324	RH or LH	1/4" Below
Arrow	2124/2324	RH or LH	1/4" Below
Best	2124/2324	RH or LH	7/32" Below
Corbin Russwin	2124/2324	RH or LH	7/32" Below
Falcon M	2124/2324	RH or LH	7/32" Below
Marks 5000	2124/2324	RH or LH	3/8" Below
Marks 7000	2124/2324	RH or LH	3/8" Below
Monarch	2114/2314	Nonhanded	1/4" Above
Precision 1300	2124/2324	RH or LH	5/16" Below
Sargent 900	2124/2324	RH or LH	3/8" Below
Sargent 7800/8200	2124/2324	RH or LH	11/32" Below
Schlage L	2134/2334	RH or LH	5/8" Below
Von Duprin 7500	2114/2314	Nonhanded	1/8" Above
Yale 4600, 8600, 8700	2134/2334	RH or LH	1-25/32" Below

VERSION 2114/2314

No (or very minimal) offset, centerline entry, nonhanded.

VERSION 2124/2324

13/16" offset from C/L of electric strike in frame to C/L of latch or 7/16" offset from C/L of lock in door to C/L of latch.

VERSION 2134/2334

1-1/16" offset from C/L of electric strike in frame to C/L of latch or 11/16" offset from C/L on lock in door to C/L of latch.

NOTE: Most locksets will not have the exact offset shown. Select from the closest version available. There are two different centerlines (C/L): the centerline of the lock in the door and the centerline of the electric strike in the frame. If the proper 2 Series model is installed, the deadlocking trigger (or auxiliary latch or guard) will not enter the pivot cavity and will function as intended. We have made every effort to ensure that the dimensions shown are accurate; however, various manufacturers' specifications may change without notice. Please confirm the dimensions shown above before ordering.

How to Hand a Door



Hand of door indicates the direction of the swing of the door. It is always viewed from outside the room, building, and so forth.

Left Hand: Door hinges are on the left when facing the door on the "push" side.

Right Hand: Door hinges are on the right when facing the door on the "push" side.