



For 2 Series Electric Strikes

*In or Out... we make it Easy!*

## Instructions

- 1) Take measurement from floor to centre line (CL) of lockset face on door.
- 2) Transfer measurement to door frame and mark CL of lockset on frame.
- 3) Align CL mark on frame with CL mark on jig (B) .
- 4) Mark frame and drill the two mounting holes (A). (These holes will be used later to install mounting tabs for electric strike) Drill and tap for #12 screws.
- 5) Attach jig to frame using screws provided.(In strike hardware pack)
- 6) For aluminum frames router cut out in the frame following the jig. (1/4 "single flute carbide bit with a 5/16" guide recommended).

For hollow metal frames, trace the cutout outline onto the door frame. Remove the jig and cut on the inside of the traced outline using a jigsaw. File corners of frame cutout to accomodate a square faceplate.

- 7) Mount **RCI** electric strike using installation instructions provided with strike.

