

Desk Top Programmer Quick Start

Install the System

1. The Desktop programmer must first be connected to the PC using the USB cable provided.
2. Insert the disc into the CD-ROM drive of the PC and close it. If setup does not automatically start, navigate to the CD-ROM drive from Windows Explorer or "My Computer" and double-click on setup.exe.
3. When the set-up process is complete, you will find a new Program Group in the Start Menu called "Proximity encoding system". You can start the program by selecting the "Proximity encoding system" icon in this program group.

Initialize the Program

Once the desktop programmer and software are installed, the system must be initialized the first time it is used. Start the program by selecting the icon in the program group in the start menu.



On startup the program will display the site creation window. A site must be created before any cards can be encoded. Simply enter the name of the site and click Add.

If the red icon and "No Encoder is Present" appears in the bottom left hand corner of the window, there is a problem with the communications to the USB Desktop Programmer.

All new sites require an Enrollment Card+, which creates the unique number sequence to be used on the site. Each new site requires its own separate Enrollment Card+.